



## Helpful Hints

**Congratulations on your purchase of the Spill Spoiler! Please read below for quick tips for easy installation**

- 1) In your product box you received four rubber feet for the Spill Spoiler. Whether you choose to install one or all of the feet, use Windex or a similar window cleaner to lubricate the slots and rubber for easy installation. For removal use both hands to hold a corner of the caddy, push down at the foot base using both thumbs.
- 2) The box has 16 rubber bumpers included within it. You will install as many as you need up to 12. We have included 4 additional rubber bumpers as well. To install push into the bottom slot first, then lift up slightly. No lubrication required.

**Thank you again for choosing Spill Spoiler for your auto care needs. We appreciate your trust and business!**